



Tantalum Lead-Free Conversion Schedule

Note: PWCs provided below refer to the date manufacturing converted 'S' suffix manufacturing to lead-free NOT the date code shipment of lead-free 'S' suffix product will begin.

To begin shipment of lead-free products with the 'S' suffix termination code, all pre-existing inventory of SnPb termination product must be depleted. The time required for this to occur will vary by part type. Therefore, should you require guaranteed lead - free supply in the interim, you must order using the 'T' suffix termination code instead

Product Series	Case Size	Standard Part Number is Lead-free on or after PWC	Conversion Status
T491, T494	A	424	Complete - June, 2004
T491, T494, T495	B	437	Complete - September, 2004
T491, T494, T495	C	510	Complete - March, 2005
T491, T494, T495	D, V	506	Complete - February, 2005
T491, T494, T495	X	427	Complete, July, 2004
T491, T494, T495	R	506	Complete - February, 2005
T491, T494, T495	S	510	Complete - March, 2005
T491, T494, T495	T	435	Complete - September, 2004
T491, T494, T495	U	512	Complete - March, 2005
T491, T494, T495	E	512	Complete - March, 2005
T492	All	N/A	None - Remains on SnPb - no change
T496	B	512	Complete - March, 2005
T496	C	510	Complete - March, 2005
T496	D, X	435	Complete, September, 2004
T510	X	446	Complete, November, 2004
T510	E	512	Complete - March, 2005
T520	B	502	Complete, January, 2005
T520	T	All	Complete, Introduced as Pb Free
T520/T530	Y	All	Complete, Introduced as Pb Free
T520/T530	X	428	Complete, July 2004
T520/T530	D	502	Complete, January, 2005
T520	V	502	Complete, January, 2005
T525	All	All	Complete, Introduced as Pb Free
A700	D,V and X	All	Complete, Introduced as Pb Free